Remote Indicator Scale

User Manual



MAN0314 - Rev 2

Doran Scales, Inc.

www.doranscales.com

Section 1. Unpacking and Care	1
Unpacking	1
Cautions and Warnings	
Care & Cleaning	
Preventive Maintenance	
Wall Mounting	2
Section 2. Battery Operation	3
Section 3. Scale Operation	
Display Pushbuttons.	
Display Annunciators	
Weighing a Patient	7
Zero Operation	7
BMI Operation	7
Reweigh Operation	7
Section 4. Specifications	3
Section 5. Troubleshooting	3
General Problem Resolution	

Section 1. Unpacking and Care

Thank you for purchasing a Doran scale. This product has been designed with the highest level of technology. We are dedicated to delivering a superior product that will provide many years of trouble free service.

As an ISO9001 registered company, Doran Scales is dedicated to delivering products built with strict compliance to our high quality standards. If you have any questions regarding your scale, please contact Doran Scales, Inc.

Unpacking

Carefully remove the scale from the shipping carton. If you notice any shipping damage, notify the shipper immediately. Be sure to retain all shipping materials in case the scale must be shipped elsewhere.

Cautions and Warnings

Normal care should be taken when handling and using this product. Improper handling or abuse can damage the scale and result in costly repairs that may not be covered by the warranty. Please observe the following precautions to ensure years of trouble free service from your new scale.

- Do not use sharp objects to press any of the buttons.
- Do not pick up the scale by the indicator or cables.
- Do not use the scale if it is damaged in any way.
- Do not leave patients unattended on the scale.
- Do not exceed the scale capacity.
- Do not drop the scale.
- Do not drop objects on the scale.
- When transporting, do not hit other objects, walls or doorframes with the scale.

Care & Cleaning

With reasonable care, this product will last for many years. Here are some tips to care for your scale. Failure to comply with these guidelines may void the warranty.


- This scale will withstand typical cleaning methods and chemicals that are used in healthcare environments. This includes but not limited to cleaners that contain sodium hypochlorite (bleach), hydrogen peroxide and alcohol.
- Do not get water inside the indicator or platform.
- Do not immerse in water or any liquid.
- Do not use strong solvents or abrasive cleaners as this can damage the touch panel or other plastic parts.

Preventive Maintenance

- Examine the scale periodically for damage and wear and tear before use.
- If the scale is damaged, check calibration of the scale and safety before use.
- Check calibration annually and calibrate if necessary.
- Remove batteries during long periods of non-use.

Wall Mounting

If mounting the indicator to a wall, refer to the following diagram. Place two screws 4.09" apart, 65" above the floor. The screw heads should be approximately 0.33" in diameter.



Section 2. Battery Operation


Battery Installation

The indicator can be powered by a set of six AA alkaline batteries. These batteries can perform over 25,000 weighments of typical use with the standard Automatic Shutoff Timer settings.

The battery compartment is located on the backside of the indicator. Press the locking tab to release battery compartment cover. Completely remove all the batteries from the indicator and install the new set of batteries. Be sure the batteries are oriented properly. Reinstall the battery compartment cover to complete the battery installation.

Battery Indicator

The battery indicator displays the remaining battery life available. A low battery status is also indicated by two beeps when a weight is held (If Parameter **b**H is set to **o**n.) This indicator will not be displayed if the scale is powered by its wall transformer.



Section 3. Scale Operation




Fig. 3 Front Panel

Display Pushbuttons

The Model DS6150 controls consist of UNITS, ZERO, REWEIGH, \blacktriangle , \blacktriangledown , and BMI buttons. The display is used to provide weight indications and operator messages indicating scale operation.

Power On/Off

Press the ZERO button to turn on the indicator. Press and hold the ZERO button for 3 seconds to turn off the indicator. The indicator has an adjustable Automatic Shutoff Timer that will turn off the indicator when not in use.

Zero

When the ZERO button is pressed, the scale will reset to zero weight. This feature can be used to zero out any weight not desired to be part of the patient weight. The current BMI entry will be changed back to a 0.0 value.

Units

Press the UNITS button to toggle between Ib and kg weighing units. The current unit will be displayed to the right of the weight digits. *NOTE: The UNITS button* can be locked or unlocked by pressing and holding UNITS for 5 seconds. An "' an" message is displayed when button is locked and "' af^{FF} " when unlocked.

Reweigh

To reinitiate the weighing process, press REWEIGH. This will allow a new measurement to be taken without the patient having to leave the platform.

BMI

With the held weight being displayed, press the BMI button to enter the height of the patient. Adjust the value by using the \blacktriangle or \checkmark buttons. *NOTE: Select the Height units by pressing the UNITS button to toggle between the height in inches or centimeters. The scale will exit this mode if no buttons are pressed within 30 seconds.*

Display Annunciators

The display annunciators will indicate the scale status.

Motion

When the scale senses motion, MOTION will be indicated. Once motion ceases, a stable reading will be displayed.

Stable Hold

Indicates a stable weight has been achieved and held on the display. This indicates an accurate weight has been achieved. *Note: Weights below 4.5 pounds will not be held.*

Average Hold

Indicates that the weight held on the display is a result of averaging several weights due to excessive motion on the scale. *Note: Weights below 4.5 pounds will not be held. The Average Hold weight may be slightly less accurate than a Stable Hold weight.*

Displaying an Average Hold weight instead of a Stable Hold weight will speed the weighment process for patients that are not able to remain still. The Average Hold weight will differ from the patient's actual weight based upon the severity of the motion caused by the patient while on the scale. Although this weight may be less accurate than a Stable Hold weight, the deviation from the patient's actual weight will be minimal.

The time required for the Average Hold to engage is based upon the Average Aperture parameter. See the Parameter Setup section for configuration instructions.

Battery Indicator

The battery indicator displays the remaining battery life. See the battery operation section for detailed information. *NOTE: The battery Indicator will be disabled when using an external power supply.*

Software Number and Revision display

Pressing and holding the REWEIGH button for 3 seconds will perform a display test. The software number, " 5_{4} [19", and the revision, "r 3.2" (or higher), are displayed first. After displaying the revision, the scale enters a "switch test" mode where the keys can be pressed to verify their operation. If no keys are pressed for 10 seconds, the scale will perform a display test and return to its normal mode of operation.

Weighing a Patient

- 1. Turn on the indicator by pressing the ZERO button.
- 2. The indicator will perform a startup zero.
- 3. The indicator will momentarily display dashes, "-----", followed by 0.0.
- 4. Patient stands on the scale platform.
- 5. The display will scroll dashes until the patient's weight is captured.
- 6. The indicator will beep (if enabled) and then hold the weight on the display until the scale turns off.

Zero Operation

- 1. Place item to be zeroed on the scale platform.
- 2. Press ZERO. The scale will display a zero weight. If the item is removed, the stable negative weight will automatically be zeroed after 3 seconds.

BMI Operation

- With the held weight displayed, press the BMI button to enter the height value. Height entry starts at 5: 5.0 or 158.0, representing 5 foot 6 inches or 168 centimeters. NOTE: Height units can be changed by pressing the UNITS button.
- 2. Press the ▲ button to increase or the ▼ button to decrease the value. When the correct value is displayed, press the BMI button to enter the value and exit. NOTE: A menu timer will exit out of this entry mode if no buttons are pressed within a 30 second time period.

Reweigh Operation

- 1. With the patient standing on the scale platform, press REWEIGH to reinitiate the weighing process.
- 2. The display will scroll dashes until the patient's weight is captured.
- 3. The indicator will beep (if enabled) and hold the weight on the display until the scale turns off.

Section 4. Specifications

Scale Platform Dimensions	12" L x 15" W x 1.5" H
Indicator Dimensions	8" L x 6.5" W x 2.3" H
Power	AC Adapter Optional: 6 AA Alkaline Batteries
Displayed Units	lb, kg
Capacity	500 x 0.2 lb or 230 x 0.1 kg
Construction	Painted Mild Steel Frame, Stainless Steel Platter and Plastic Indicator Housing.
Options	RS-232 Communication cable USB Communication cable WiFi

Section 5. Troubleshooting

General Problem Resolution

Problem Resolution	What to Do or Check
Weight reading will not repeat or	Person or object other than that being
scale does not return to zero when weight is removed.	weighed is touching the scale.
5	Verify that there is nothing caught in or interfering with the platform.
Scale overloads before scale capacity is reached.	Verify scale calibration is correct. If problem persists, recalibrate the scale.
Scale will not come to zero when the ZERO button is pressed.	Make sure that the scale is stabilizing (Motion annunciator is off). After pressing the ZERO button, the scale should zero as soon as it becomes stable.
Weight readings are not correct.	Verify the scale calibration with an accurate set of test weights. If the readings are not correct, recalibrate.
	Be sure the platform is on a flat surface and all four feet are touching the floor.
Scale drifts off zero.	Check for air currents and/or vibration around the scale.
Scale shuts itself off or will not turn on.	Press the ZERO button to turn on the indicator.
	Check that new batteries are installed properly in the battery tray.
	If using an AC adapter, confirm that it is firmly plugged into a functioning wall outlet.
	Verify the connector at the rear of the indicator is properly installed.

Doran Scales, Inc. 883 Enterprise Court St. Charles, IL 60174

www.doranscales.com

630-879-1200